Manual Instruction of Timer Socket

➢ **Product name:** One-week Mechanical Indoor Timer Socket

➢ **Barcode:** 8433325179502

➢ **Plug parameter:** 230V/50Hz16(2)A

➢ **Picture:**

➢ **Product introduction**

1. There is a mode setting slider on the right side of the product. To activate the socket at regular intervals, toggle the slider so that the icon ⏲ is visible, otherwise toggle it backwards so that the icon Ⅰ is visible, indicating that the socket is always powered on. (As in fig. 1)

2. When the socket is in timer mode, the power indicator lights up. (As in fig. 2)

3. Above the socket is a time dial indicating the seven days from Monday to Sunday. The 24 hours per day are divided into 12 compartments, each with a 2-hour interval for the dial (see fig. 3). Press = on, pop up = off.

4. The time dial can only be turned in a clockwise direction, not counterclockwise.

5. The small triangle is set to point to the current time.

Manual Instruction of Timer Socket

fig. 1

fig. 2

fig. 3

> **Timer mode instruction**

1. Toggle the right mode setting slider so that the icon ⊙ is visible and the timer function is on.

2. Calibrate the current time: turn the dial clockwise so that the arrow points to the current time.

3. Press the black paddle on the dial to set the date and time period for which you want to energize the socket. Each paddle is for 2 hours and when pressed the socket is set to energize for that period of time.

4. Plug the timer into the power supply (timer indicator lights up), then plug the appliance to be used into the timer socket and turn on the appliance switch. When the time goes to the set time period, the appliance will be automatically energized to work.

Manual Instruction of Timer Socket

➢ **Examples:**

It is now 12:00 noon on Wednesday and you want the appliance to work from 00:01-12:00 on Friday. Firstly, ensure that the icon 🕐 on the right side of the mode setting slider is visible. Then, turn the time dial clockwise so that the arrow is pointing to WED 12:00 (as in fig. 1). Finally, press down the six paddles from FRI 00:01 to 12:00 (as in fig.2). By this way, the appliance will work automatically during that time period.

fig. 1

fig.2

Note: If the timer function is temporarily not required, toggle the slider towards the other end so that the icon I is visible and the timer function is switched off (timer indicator turns off). The socket will be kept energized at all times.